




Pos.	Artikelbeschreibung	Description of item	Artikel Nr./Item No.
1	Abdeckblech	Cover plate	0SL0002
2	Welle	Shaft	0SL0021
3	Lager	Bearing	0SL1799
4	Kupplung	Coupling	0SL2524
5	Hülse	Bush	0SL2617
6	Stift	Pin	0SL2624
7	Zahnrad 3/8" x 7/32" Z=15	Gear wheel 3/8" x 7/32" Z=15	0SL0024
8	Kette 3/8" x 7/32"	Chain 3/8" x 7/32"	0SL2681
9	Schaltnocken	Switch cam	0SL0035
10	Mikroschalter	Mikroswitch	0SL0885
11	Winkel	Angle	0SL0397
12	Zahnrad 3/8" x 7/32" Z=29	Gear wheel 3/8" x 7/32" Z=29	0SL0030
13	Lagerbock UCF204	Bearing block UCF204	0SL0032
14	Gehäusekasten, oben	Upper housing element	0SL2574
15	Elektronik 230V, 1Ph, 50Hz	Electronics 230V, 1Ph, 50Hz	0SA1220
16	Abdeckung, hinten	Back cover plate	0SL2845
17	Lagerbock	Bearing block	0SL0022
18	Passfeder 5 x 5 x 20 mm	Key 5 x 5 x 20 mm	A0SL0010
19	Passfeder 8 x 7 x 40 mm	Key 8 x 7 x 40 mm	0SL3410
20	Welle	Shaft	0SA1023
21	Getriebe	Gear	0SL3186
22	Motor 230V, 1Ph, 50Hz	Motor 230V, 1Ph, 50Hz	0SL3212
23	Zugentlastung PG11	Strain relief PG11	0SL1668
24	Anschlusskabel 230V, 1Ph, GND	Power cord 230V, 1Ph, GND	A0SL1671
25	Fuß	Base	0SL3361
26	Gehäuse	Housing	0SL3358
27	Gehäuse z. Schalter	Housing f. switch	0SL0937
28	Dichtung z. Gehäuse	Gasket f. housing	0SL0396
29	Schalter "Stop"	Switch "Stop"	0SL0807
30	Schalter "Start"	Switch "Start"	0SL1049
31	Zahnrad 8 x 3 Z=85	Gear wheel 8 x 3 Z=85	0SL0057
32	Kette 8 x 3	Chain 8 x 3	0SL2682
33	Stange	Rod	0SL3370
34	Achse, klein	Small axle	0SL0014
35	Lager 6203 2RS	Bearing 6203 2RS	E0SL0131
36	Lagerbock	Bearing block	0SL0016
37	Sicherungsring Ø 17	Locking ring Ø 17	0SL0017



Teigknetmaschine 18kg, 22L
Artikel-Nr.: 101865

Ersatzteilliste
07.03.2016

Pos.	Artikelbeschreibung	Description of item	Artikel Nr./Item No.
38	Lager 6203 2RS	Bearing 6203 2RS	E0SL0131
39	Mutter z. Schalnocken	Nut f. switch cam	0SL0036
40	Halterung z. Rad	Holder f. wheel	0SL2603
41	Buchse	Bush	0SL1090
42	Rad	Wheel	0SL2655
43	Feder	Spring	0SL2667
44	Knethaken	Dough hook	0SL0011
46	Sicherungsring Ø 25	Locking ring Ø 25	0SL161
47	Lagerbock	Bearing block	0SL2626
48	Mikroschalter	Microswitch	A0SL1401
49	Flansch	Flange	0SL2620
50	Platte	Plate	0SL2633
51	Dichtung	Sealing	0SL1890
52	Arretierungsschraube	Locking screw	0SL2622
53	Halteplatte	Supporting plate	0SL2635
54	Schüssel	Bowl	0SA1160
55	Deckel z. Schüssel	Lid f. bowl	0SA1005
57	Schutzblech	Protection plate	0SL2876
58	Kupplungsbolzen	Coupling shaft	0SL2615
60	Abdeckblech	Cover plate	0SL2580
61	Kettenschloss 3/8" x 7/32"	Chain joint 3/8" x 7/32"	0SL1629
62	Kettenschloss 8 x 3	Chain joint 8 x 3	0SL1545
63	Lenkrollen 4TKM	Wheel set 4 pieces	101863
64	Bolzen	Pin	0SL2629
65	Geschwindigkeitsregler, 2-Stufen	Speed regulator, 2-levels	n.m.lieferbar/n.available
67	Lenkrollen 4TKM	Wheel set 4 pieces	101863
69	Abdeckung, nicht rostend	Cover, stainless steel	0SL3418
70	Schalter	Switch	0SL0054
72	Bügel	Clamp	0SL4089
73	Mikroschalter	Microswitch	0SA1140
74	Sicherung	Fuse	0SL4118
75	Fühler	Sensor	0SL4103
76	Platine	Circuit board	0SL4116



Teigknetmaschine 18kg, 22L
Artikel-Nr.: 101865

Ersatzteilliste
07.03.2016